

AWARNING: Avoid serious injury or death to your child. You must read and understand the Car Seat Adapter/Basket Feature instructions and the instructions in the User Guide. If you do not understand these instructions, STOP and call Chicco at 1-877-424-4226.


SS0040E 03

INSTRUCTIONS: Corso® Flex Car Seat Adapter/Basket


IMPORTANT: Please also refer to the instructions that came with your product.

Infant Car Seat Adapter and basic function:


- The Infant Car Seat Adapter will only attach to the stroller frame in one direction.
- The Infant Car Seat Adapter can be attached to the stroller frame in either the Upper or Lower Modular Positions.
- A Chicco Infant Car Seat will only attach to the Infant Car Seat adapter in one direction, Parent-Facing. The Infant Car Seat Adapter includes a fabric basket that can be used as an additional storage basket.
- The Infant Car Seat Adapter fabric basket can be removed by unsnapping the fabric attachment points (10 snaps) from around the adapter frame.




- The Infant Car Seat Adapter can be used without the fabric basket to attach a Chicco Infant Seat to the stroller.
- The Infant Car Seat Adapter can be used with the fabric basket to attach a Chicco Infant Seat to the stroller. Do not store anything in the basket when attaching a Chicco infant seat.




The Modular Seat can be removed to attach the Infant Car Seat Adapter. To remove the Modular Seat, press the buttons inside both hubs, as shown, and lift up to remove the seat.




Open the adapter hoop and locate the upward bend in the adapter. This bend always faces to the front of the stroller. Line up the Tongues on both sides of the Infant Car Seat Adapter to the slots on the Stroller frame as shown. Push down until it clicks into place. Pull up on the Infant Car Seat Adapter to make sure it is securely attached to the Stroller Frame.




³ When using an Infant Car Seat with the Lower Modular position IN. Make sure the Grip Bar is removed before placing the Infant Car Seat into the adapter, or use the Lower Modular Position OUT. With the Infant Car Seat Adapter attached, place the Chicco infant car seat into the adapter (3A). The infant car seat can only be attached in a Parent-Facing position. Make sure infant car seat clicks into the Infant Car Seat Adapter on both sides. Pull up on the infant car seat; make sure it is secured to Stroller Frame (3B).



To remove the infant car seat, squeeze the Release Handle on the back of the infant car seat and lift up on the carrying handle.



5 To fold the Infant Car Seat Adapter when not in use. Lift up on the front frame and rotate the frame towards the back frame.



[©] To remove the Infant Car Seat Adapter, press both buttons on the attachment and pull up.