

CORSO

PARENT STASH ORGANIZER

KEEP THESE INSTRUCTIONS FOR FUTURE USE

Owner's Manual

SS0050E_04 ChiccoUSA.com

A WARNINGS

READ ALL INSTRUCTIONS BEFORE USE - Failure to follow these warnings and instructions could result in injury or death to your child. Keep these instructions for future use.

- STRANGULATION HAZARD: Child can strangle in loose straps.
 NEVER leave child alone with this product.
 ALWAYS store the Waist Belt Straps when not wearing the parent organizer.
- AVOID TIPPING: Do not place more than 2 lbs (0.9 kg) in the parent organizer.
- AVOID BURNS: Never put hot liquids in parent organizer.
- NEVER place items such as purses, shopping bags, accessories, or parcels on the parent organizer or handle.


THIS KIT INCLUDES:



Parent Stash Organizer x1

USING THE ORGANIZER


The Corso Parent Stash Organizer is compatible with most strollers, but was designed on the Corso Stroller platform.



3a. Wrap one Strap around the Stroller Handle above the Handle Adjuster Button and push it up through the adjuster loop.

3b. To secure on handle, pull down firmly on the Strap and attach the Hook and Loop.

3c. Rotate the Strap so the D-ring is hanging down, as shown. Repeat Step 3 for the other Strap.




4. Attach both clips on the Parent Organizer to the Handlebar Straps.


USING THE ORGANIZER (cont.)


Important: Never put hot liquids in the Parent Organizer.

- **5.** The outside of the Parent Organizer has 1 zippered pouch on the front panel. The inside of the Parent Organizer has 1 zippered pouch on the back panel and 3 divided storage compartments.
- **6.** To create the 3 separate storage compartments in the Parent Organizer attach dividers to the hook and loop on the inside of the Parent Organizer.




WEARING THE ORGANIZER






1. Un-clip the Parent Organizer from the stroller. Secure both of the Hanging Straps to the D-rings on the sides of the Parent Organizer, as shown.

2. Pull both waist belt storage pockets out that are secured behind the mesh on the back of the Parent Organizer.






3. Unroll the Waist Belt Straps from both storage pockets.

WEARING THE ORGANIZER (cont.)

4. Buckle the Waist Belt Straps and adjust the length of the belt by pulling on the loose ends.








5. The Parent Organizer can be worn around the waist or can be worn crossbody, as shown.


STORING THE WAIST BELT STRAPS

Important: Always store the Waist Belt Straps when not wearing the Parent Organizer.

1. Roll up both of the Waist Belt Straps and tuck them inside the storage pockets, as shown.

2. Fold the storage pockets behind the mesh panel on the back of the Parent Organizer. Ensure hook and loop is is secured to store straps.





CLEANING

Spot clean with mild soap and water, or machine wash in cold water on delicate cycle using mild detergent. Attach hook and loop parts together before washing. Hang to dry. DO NOT BLEACH.

If product is broken or damaged stop use and contact Chicco Customer Service at 1-877-424-4226.

[Kee-Ko] If you say it right it makes you smile

