



Lift up on the plastic tabs at the top of the Headrest and below the Shoulder Belt Guides, as shown.



16 Pull the Seat fabric cover forward to remove.

#### TO RE-ATTACH SOFTGOODS:





To re-attach Armrest covers refer to the USER GUIDE.

To re-attach zip padding repeat steps 2 thru 8 in REVERSE.

To re-attach fabric covers repeat steps 11 thru 16 in REVERSE. Make sure to insert the Foam Pad into the fabric seat bottom before you re-install onto the seat bottom frame. Be sure to fit fabric cover carefully around all orange belt guides.

The Booster Seat must never be used without the fabric covers. It may not perform as intended in the event of a crash.

# **Cleaning Instructions:**

Fabrics may be spot-cleaned with mild soap and water, or machine washed in cold water on delicate cycle using mild detergent. Hang to dry. **DO NOT BLEACH.** 

Please consult your product manual for additional care and maintenance instructions.

Contact Chicco Customer Service at **1-877-424-4226** for assistance in removing or replacing the softgoods.




⚠WARNING: Avoid serious injury or death to your child. Never use your KidFit booster seat without the softgoods in place. You must read and understand the Softgood Removal instructions and the instructions in the User Guide. If you do not understand these instructions, DO NOT attempt to remove the Softgoods, STOP and call Chicco at 1-877-424-4226.


# **INSTRUCTIONS:** KidFit Zip Softgood Removal

IMPORTANT: Please also refer to the instructions that came with your product.


## TO REMOVE THE ZIP PADDING:




The KidFit Zip has four interchangeable pads (purchased separately). The Back Pad, the Bottom Pad and the two Armrest covers.




Squeeze the Height Adjustment Lever on the back of the Headrest and pull up to raise the Backrest.




2 Unzip zipper on the top of the Headrest (as shown.)



4 Unzip zipper on the Backrest (as shown).




Unhook both elastic straps on the back of the Backrest (as shown).




Flip the Booster seat bottom over and remove both Tabs on the front of the Booster seat.

**6 Unzip the zipper** on the back of the Booster seat bottom.




8 Remove both the Bottom Pad and Back Pad from the Booster seat bottom and Backrest.

## TO REMOVE THE ARMREST COVERS:




Description 2 Locate the Armrest release button directly under the front of the Armrest. Pull on the button and at the same time lift up on the front edge to remove the Armrest cover.




10 Pull back on the edges of the Armrest cover and slide the fabric off the Armrest base.


### TO REMOVE THE FABRIC COVERS:




Remove the Cup Holders press in on the release button on the bottom of the Booster Seat.



12 Flip the Booster Seat bottom over and unhook 8 elastic loops (as shown).



Remove the fabric cover from the Booster seat bottom. Flip the fabric over and remove the Foam Pad before you wash the fabric.



On the Booster Backrest, unhook 6 elastic loops as shown. Four behind the Headrest and two at the bottom of the seat back.

2