



Read all instructions **BEFORE** assembly and **USE** of product.


KEEP INSTRUCTIONS FOR FUTURE USE.

BENTO™

3-in-1 Booster Chair

⚠️ WARNING Failure to follow the warnings and the instructions throughout this booklet could result in serious injury or death. Each mode has specific warnings, make sure to read and understand the warnings in each mode.


This product can be used in the following modes:



BOOSTER SEAT Mode




FEEDING CHAIR Mode




TODDLER CHAIR Mode

Parts List




A. - Seat Base



B. - Tray

Components




A - Backrest
 B - Rear Attachment straps
 C - Lower Attachment straps
 D - Seat
 E - Harness Straps
 F - Tray Supports
 G - Seat Release Lever

H - Carry Handle
 I - Tray Attachments
 J - Tray Horn
 K - Storage for Rear and Lower Attachment Straps
 L - Leg Release Levers

Assembling the Seat


1





1. On the bottom of the Booster Seat, locate the Booster Legs. Rotate both Legs out until they lock with a click, as shown.

Assembling the Seat

2



2. To unfold the Booster Seat, squeeze the Fold Lever and lift up on the Seat Back until it locks with a click.




Assembling the Seat


⚠ WARNING

The tray is not designed to hold the child in the chair.

3



3. To attach the Tray to the seat frame, line up the Tray with the Tray Supports. Slide both Tray Attachments onto the Tray Supports until they click into position. Pull out on the Tray to make sure it is securely attached.




⚠️ WARNING

BOOSTER SEAT MODE


Children have suffered severe head injuries, including skull fractures, after falling with or from boosters.

- Check that booster seat is securely attached to adult chair before each use.
- Always use restraints until child is able to get in and out of booster seat without help. Adjust to fit snugly.
- Never allow child to push away from table.
- Never lift and carry child in booster seat.
- Stay near and watch your child during use.
- Until child is able to get in and out of the booster seat without help (about 2 ½ years old), the child should be secured in the booster seat at all times by the restraint system. The tray is not designed to hold the child in the chair.
- Never allow child to sit in unsecured chair. Always secure the booster seat to chair using both attachment straps. Always check that the attachment is secure before each use.
- Prevent serious injury or death. Do not use in motor vehicles.
- Use this booster only for children capable of sitting upright unassisted.




- Do not use for children weighing more than 50 lbs (22.7 kg).
- Do not use on any elevated surface other than a full sized dining room chair.
- Never fit the booster seat to damaged or unstable chairs, folding chairs, pedestal chairs or bar stools.
- Only use on chairs with a seat at least 15 5/8 inches (39.7 cm) wide, 14 1/4 inches (36.2 cm) deep, and a backrest at least 12 inches (30.5 cm) high.
- Always check that the surface of the floor is even and the chair is stable before fitting the booster seat to the chair.
- Do not use the product if any part is broken or missing.
- Ensure that all components are correctly fitted and adjusted before use.
- To avoid the danger of suffocation, remove all plastic covers before using the product.
- Do not leave the product near walls, curtains, or windows, where the child can become entangled.
- Do not attach any parts to the product that are not supplied or expressly approved by Chicco.


Attaching the Booster Seat to a Chair



4A. Remove the Rear Attachment Straps and the Lower Attachment Straps from the Storage Compartment, as shown.




4B. Make sure to thread the Rear Attachment Straps through the vertical guides on the back of the Seat.



Attaching the Booster Seat to a Chair


5



High Position Install:

5. Center the seat on the chair, making sure the back of the Booster Legs are against the chair back.


6A



6A. Insert the Rear Attachment Straps through the vertical guide slots on the back of the Seat (Step 4B).

Fasten the Rear Attachment Straps, passing them behind the backrest of the chair. Pull the Rear Attachment Strap snug - Do not fully tighten.


6B



6B. Then fasten the Lower Attachment Straps, passing them underneath the seat of the chair. Pull the Lower Attachment Strap snug - Do not fully tighten.



Attaching the Booster Seat to a Chair

7





7. Make sure the Booster Legs are not overhanging the chair seat and the Booster is centered, then secure the Booster by fully tightening the Rear and Lower Attachment Straps as shown.

Once tight, pull on the seat and make sure attachment straps do not become loose. If they become loose, reposition the straps and retighten to make sure the straps do not become loose.




Attaching the Booster Seat to a Chair




Low Position Install:


8. To Fold the Booster Seat Legs, pull on the Leg Release Lever and rotate the Booster Leg in towards the bottom of the Seat. Repeat for the other Leg.



Attaching the Booster Seat to a Chair




9. Center the seat on the chair, making sure the back of the Booster Seat is against the chair back.



10A. Insert the Rear Attachment Straps through the guide slot on the back of the Seat (Step 4B).


Fasten the Rear Attachment Straps, passing them behind the backrest of the chair. Pull the Rear Attachment Strap snug - Do not fully tighten.



10B. Then fasten the Lower Attachment Straps, passing them underneath the seat of the chair. Pull the Lower Attachment Strap snug - Do not fully tighten.



Attaching the Booster Seat to a Chair

11




11. Make sure the Booster Legs are not overhanging the chair seat and the Booster is centered, then secure the Booster by tightening the Rear and Lower Attachment Straps as shown.

Once tight, pull on the seat and make sure attachment straps do not become loose. If they become loose, reposition the straps and retighten to make sure the straps do not become loose.



Removing the Tray


12



12. To remove the Tray from the Tray Supports, pull out on both side tabs and lift up.


Using the 3-point Harness

13A




13A. Unfasten the 3-point harness by pressing the center button on Crotch Strap Buckle. Pull out both Waist Clips from the Crotch Strap Buckle.

13B



13B. To fasten the 3-point harness, slide both Waist Clips into the Crotch Strap Buckle. Pull on both sides to make sure the Waist Clips are secured to the Crotch Strap Buckle.

13c



13C. Adjust the 3-point harness to fit your child.

The length of the Waist Straps can be adjusted by pressing the tab at the end of the Waist Strap Clip and pulling on the strap to tighten or loosen to better fit your child.


The length of the Crotch Strap can be adjusted by pulling on the adjustment buckle to tighten or loosen.

! WARNING

FEEDING CHAIR MODE

FALL HAZARD: Infants have suffered skull fractures falling while in and from floor seats.

- Use ONLY on the floor.
- NEVER use on an elevated surface.
- ALWAYS use restraints. Adjust to fit snugly.
- NEVER lift or carry child in the product.
- Use ONLY with a child that is able to hold their head up unassisted.
- Do not use for children weighing more than 50 lbs (22.7 kg).
- STOP using as a floor seat when the child can climb out or walk.
- ALWAYS keep child in view while in product.
- Do not use the product if any part is broken, torn, or missing.
- Ensure that all components are correctly fitted and adjusted before use.
- To avoid the danger of suffocation, remove all plastic covers before using the product.
- Do not leave the product near walls, curtains, or windows, where the child can become entangled.
- Do not attach any parts to the product that are not supplied or expressly approved by Chicco.




DROWNING HAZARD: Infants have drowned when floor seat has been placed in a bath tub or pool.

- NEVER use in or near water.

Storing the Attachment Straps

14




14. To store the Rear and Lower Attachment Straps; fold and tuck each strap into their corresponding openings, as shown. Store the straps for later use.


WARNING

TODDLER CHAIR MODE

- Use ONLY on the floor.
- NEVER use on an elevated surface.
- Do not use for children weighing more than 50 lbs (22.7 kg).
- ALWAYS keep child in view while in product.
- Do not use the product if any part is broken, torn, or missing.
- Ensure that all components are correctly fitted and adjusted before use.
- To avoid the danger of suffocation, remove all plastic covers before using the product.
- Do not leave the product near walls, curtains, or windows, where the child can become entangled.
- Do not attach any parts to the product that are not supplied or expressly approved by Chicco.
- DROWNING HAZARD: NEVER use in or near water.





Removing the 3-point Harness Straps




Refer to previous section for tray removal (step 7).




15. Undo the harness buckle. Loosen the Crotch Strap Tab by pushing the Crotch Strap down into the opening in the Seat bottom, as shown. Pull out the folded Crotch Strap Tab. Flatten the Crotch Strap Tab and feed it back up through the opening in the Seat bottom.



Removing the 3-point Harness Straps



16. Loosen the Waist Belt Strap Tab, then push the Waist Belt Strap down into the opening in the Seat bottom, as shown. Pull out the folded Waist Belt Strap Tab. Flatten the Waist Belt Strap Tab and feed it back up through the opening in the Seat bottom.





Closing and Transporting the Seat

17

17. Squeeze the Locking Lever on rear of Seat Back and rotate the Seat Back forward.

Note: The Tray can be attached when folding the Booster Seat.



Cleaning and Maintenance

This product requires regular maintenance. The cleaning and maintenance of the product must only be carried out by an adult.

CLEANING

Do not use bleach, spray, or wipes on this product.

Periodically wipe clean plastic parts with a soft damp cloth. Always dry the metal parts to prevent the formation of rust if the product has come into contact with water.

- Dishwasher-safe tray, top rack only

MAINTENANCE

Periodically check the product for loose screws, or worn parts. Replace or repair the parts as needed. Use only Chicco replacement parts. Keep product in a dry place. Prolonged exposure to direct sunlight may cause plastic parts to warp.

For More Information

For USA customers :
If you have any questions or comments about this product, or are missing any of the parts, please do not return this product to the store.
Contact us in one of the following ways:



(877)-424-4226



info.usa@artsana.com




www.chiccousa.com



1826 William Penn Way
Lancaster, PA 17601

[**Kee-Ko**] If you say it right it makes you *smile*



KEE-KO