




Read all instructions BEFORE
assembly and USE of product.
KEEP INSTRUCTIONS FOR
FUTURE USE.



SideKick™

Hip Seat Carrier

Owner's Manual


! WARNING

Failure to follow these warnings and the instructions could result in serious injury or death


•FALL HAZARD -

- Before each use, make sure all buckles, snaps, straps, and adjustments are secure.
- Take special care when leaning or walking.
- Never bend at waist; bend at knees.
- Keep arm around child at ALL times when using the carrier.
- Only use this carrier for children between 4 months to 33 lbs (15 kg).
- The carrier must only be worn by an adult.
- Always properly fit the carrier on you before sitting the child on it.
- Check for ripped seams, torn straps or fabric and damaged fasteners before each use.
- Never use carrier when balance or mobility is impaired because of exercise, drowsiness, or medical conditions.
- Use the carrier only while standing or walking.
- Never use the carrier while engaging in activities such as cooking and cleaning which involve a heat source or exposure to chemicals.
- While using carrier be aware that your balance may be adversely affected by Child's movement.
- This carrier is not suitable for use during sporting activities.
- Never wear the carrier while driving or being a passenger in a motor vehicle.
- Do not seat more than one child at a time on the carrier.
- Do not attach any parts to the carrier that are not supplied or expressly approved by Chicco.
- Before use, remove and dispose of plastic bags and other packaging materials, and keep them out of reach of babies and children.

Components



- A. Waist Belt
- B. Waist Belt Buckle
- C. Adjustment Strap
- D. Seat Wedge
- E. Storage Pocket



Hip Seat Mode

⚠️ WARNING

Only use Hip Seat for children 4 months old to 33 lbs (15 kg). Keep arm around child at ALL times when using Hip Seat.

1




Parent Facing
4m+

The Hip Seat can be used in the following positions.




Carrying on Hip
4m+






Outward Facing
6m+

Hip Seat Mode


2



2. Wrap the Waist Belt around your waist and attach the hook and loop sections together. Then buckle the Waist Belt Buckle. Pull on the Adjustment Strap until snug. Roll up the excess length of strap from bottom up and secure it with the elastic band, as shown. Turn the Hip Seat to the front or onto your hip.



Cleaning and Maintenance



HIP SEAT CARE:

Before washing the Hip Seat, remove the wedge from the compartment by unzipping the zipper. Spot clean with damp cloth and mild, soapy water. Or hand wash only in warm soapy water. Air dry. After each washing check that the fabric and seams are not worn or damaged.

HIP SEAT MAINTENANCE:

Check the seams and Hip Seat regularly to ensure that they are not worn or damaged, and that no part is missing. If any part is worn or missing, do not use this product.

For More Information

For USA customers :

If you have any questions or comments about this product, or are missing any of the parts, please do not return this product to the store. Contact us in one of the following ways:



(877)-424-4226



info.usa@artsana.com



www.chiccousa.com



1826 William Penn Way
Lancaster, PA 17601



www.chiccousa.com